

AIR CIRCUIT BREAKERS

DMX³

EFFICIENT
PROTECTION
UP TO 6300 A



MAY 2021

→ CATALOGUE PAGES INSIDE

THE GLOBAL SPECIALIST
IN ELECTRICAL AND DIGITAL BUILDING INFRASTRUCTURES

 **legrand**[®]

DMX³ ACBs UP TO 6 300 A

EFFICIENT
PROTECTION
AND CONTROL
FOR ALL TYPE
OF INSTALLATIONS



DMX³ frame 2500



DMX³ frame 4000



DMX³ frame 6300

Draw-out DMX³ frame 2500



Key locking in "Open" position

Open control button

MP4 LSig tripping unit


Reset button

Indicator showing the position of the main contacts O / I

Optimized performance up to 6300 A

DMX³ air circuit breakers and DMX³-I isolating switches are available in Three frame sizes. Three breaking capacities for circuit breakers: 50 kA, 65 kA and 100 kA.

The range covers 11 rate currents, between 630 A and 6 300 A.
All range of DMX³ air circuit breakers and DMX³-I isolating switches is available in fixed and draw-out version.



BREAKING CAPACITIES AND RATED CURRENT

	630 A	800 A	1000 A	1250 A	1600 A	2000 A	2500 A	3200 A	4000 A	5000 A	6300 A
DMX^{3-N}	50 kA FIXED/DRAW-OUT										-
DMX^{3-H}	65 kA FIXED/DRAW-OUT										-
DMX^{3-L}	100 kA FIXED/DRAW-OUT										100 kA F/D-0

OVERAL DIMENSIONS AND WEIGH

Fixed version

		Height	Depth	Width	Weight ⁽²⁾
FRAME 1600 50 kA	3P	321 mm	203 mm	254 mm	20 kg
	4P	321 mm	203 mm	324 mm	25 kg
FRAME 2500 50 / 65 kA	3P	419 mm	354 mm	273 mm	41 kg
	4P	419 mm	354 mm	358 mm	48 kg
FRAME 4000 50 / 65 / 100 kA	3P	419 mm	354 mm	408 mm	59 kg
	4P	419 mm	354 mm	538 mm	76 kg
FRAME 6300 100 kA	3P	419 mm	354 mm	797 mm	118 kg
	4P	419 mm	354 mm	1064 mm	152 kg



Draw-out version

		Height	Depth	Width	Weight⁽³⁾	
FRAME 1600 50 kA	3P	352 mm	306 mm	282 mm	39 kg	
	4P	352 mm	306 mm	352 mm	49 kg	
FRAME 2500 50 / 65 kA	3P	465 mm	433 mm	327 mm	77 kg	
	4P	465 mm	433 mm	412 mm	94 kg	
FRAME 4000 50 / 65 / 100 kA	3P	465 mm	433 mm	425 mm	108 kg	
	4P	465 mm	433 mm	555 mm	137 kg	
FRAME 6300 100 kA	3P	465 mm	433 mm	804 mm	216kg	
	4P	465 mm	433 mm	1064 mm	274 kg	



(?) For trip-free switches please consult us

(3) Including base



**LEGRAND
ADVANTAGE**

The overall dimensions of the breaker contribute considerably to an efficient use of the space inside the electrical panel. The constant depth for all the rated currents, for the frames 2500, 4000 and 6300 facilitates configuration of the enclosures and connection of the busbars.




OTHER ELECTRICAL FEATURES

Rated operational voltage Ue: 690 Vac 50/60 Hz
Rated insulation voltage Ui: 1 000 Vac 50/60 Hz
Rated impulse withstand voltage Uimp: 12 kV
Category of use: B
Ambient temperature: - 25 °C to 70 °C
Humidity: + 55 °C with relative humidity of 95%,
conforms to IEC 68-2-30

(1) Available only on DMX³ 2500, 4000 and 6300.

MP4 LSig
electronic
protection uni
for DMX³ 2500
to 6300



Precise & user friendly LCD tripping units

Besides their easy mounting and connection strength and good continuity of operation, 3 types of electronic units allow precise adjustment of different limits for current values and time delay.

The result is an efficient protection against electrical faults while maintaining total discrimination with downstream breakers.


The LCD display lets you monitor the measured current values and informs you on fault adjustment and log (the cause of last trip and maintenance operations).

MP4 LI ELECTRONIC PROTECTION UNIT CAT. NOS. 0 281 64 AND 0 288 00



The following settings are adjusted using rotary selector switches:

- Long time delay protection against overloads: **I_r**
 - Long delay protection operation time: **tr**
 - Instantaneous protection against very high short circuits: **I_i**
 - Neutral protection: **I_N**




MP4 LSI ELECTRONIC PROTECTION UNIT CAT. NOS. 0 281 65 AND 0 288 0



The following settings are adjusted using rotary selector switches:

- Long time delay protection against overloads: **I_r**
 - Long delay protection operation time: **tr**
 - Short time delay protection against short circuits
 I_{sd}
 - Short time delay protection operation time: **tsd**
 - Instantaneous protection against very high short circuits: **I_i**
 - Neutral protection: **I_N**




MP4 LSIG ELECTRONIC PROTECTION UNIT CAT. NOS. 0 281 66 AND 0 288 0



The following settings are adjusted using rotary selector switches:

- Long time delay protection against overloads: **Ir**
 - Long delay protection operation time: **tr**
 - Short time delay protection against short circuits
tsd
 - Short time delay protection operation time: **tsd**
 - Instantaneous protection against very high short circuits: **li**
 - Earth fault current: **lg**
 - Time delay on earth fault tripping: **tg**
 - Neutral protection: **In**



**LEGRAND
ADVANTAGE**


All protection units of DMX³ 2500 to 6300 are equipped with batteries so you can monitor the parameters even when the breaker is not connected and all data remains stored in memory.



MORE INFORMATION

All DMX³ breakers are factory equipped with any MP4 protection unit LI, LSI or LSIG according to your requirements. You just need to select and indicate the 2 catalogue numbers when placing the order (1 for the breaker and 1 for the tripping unit).

MP6 LSI touch screen protection unit



Innovative & user friendly touch screen tripping units

MP6 electronic protection units are equipped with a colour touch screen, particularly user friendly thanks to intuitive icon-based navigation system. The colour display provides a clear presentation of the parameters of the installation.

Touch screen protection units integrate all the functions of LCD tripping units and have an advanced measurement function which, in addition to monitoring currents, can also be used to display voltages, active and reactive powers, frequency, power factor, and also energy.

Alarms can be programmed on a number of these parameters: max voltage, min. voltage, voltage imbalance, max. and min. frequency, etc.


MP6 LSI TOUCH SCREEN PROTECTION UNIT CAT.NO. 0 288 03



Tripping curve preview

The following settings are adjusted using the touch screen:

- Long time delay protection against overloads: **I_r**
 - Long delay protection operation time: **t_r**
 - Short time delay protection against short circuits: **I_{sd}**
 - Short time delay protection operation time: **tsd**
 - Instantaneous protection against very high short circuits: **li**
 - Neutral protection: **I_N**




MP6 LSIG TOUCH SCREEN PROTECTION UNIT CAT.NO. 0 288 04



Earth fault tripping curve preview

The following settings are adjusted using the touch screen:

- Long time delay protection against overloads: **Ir**
 - Long delay protection operation time: **tl**
 - Short time delay protection against short circuits: **Isd**
 - Short time delay protection operation time: **tsd**
 - Instantaneous protection against very high short circuits: **li**
 - Earth fault current: **Ig**
 - Time delay on earth fault tripping: **tg**
 - Neutral protection: **In**



**LEGRAND
ADVANTAGE**

The icon-based interface of the management software and the innovative touch screen technology used for MP6 tripping units simplify setting and preparing operations of the DMX³ circuit breaker.



**MORE
INFORMATION**

The MP4 and MP6 electronic protection units of the DMX³ ACBs equipped with communication option Cat.No 0 288 05 or 0 281 70 can communicate via an RS-485 port. This port is used for supervising

(remote monitoring and management) the devices in the installation, using the MODBUS protocol. It is therefore possible to control circuit breaker opening and closing, display the electrical parameters and detect all the alarms generated by each device, from a PC.

Power Control Station is a software application for PCs allowing to exchange data with the protection unit of the DMX³ through the mini USB port.

This software allows to monitor the status of the breaker, display information (firmware and device versions, alarms, measurements, parameters, fault history, settings), update the firmware of the protection unit, generate reports based on the data stored and read by the protection unit, run diagnostic tests.

STARTING MENU



This menu displays the values of I_1 , I_2 , I_3 and I_N as a diagram, the date and the hour, and the alarm icon. If the breaker opens following an electrical fault a specific icon will appear on the upper part of the screen. Pressing this icon will open a new window showing the cause of the last event.

- Right arrow icon: access the main menu
- Alarm icon: preview the cause of the alarm in course

MAIN MENU



The main menu allows accessing different windows for setting different parameters of the breaker or previewing measured values, battery status, tripping history, etc.

The following accesses are possible:

- 1 Setting according to the tripping curves (current and time)
- 2 Access tripping unit settings (luminosity, contrast and sound volume)
- 3 Access to general information of the breaker
- 4 Back to the previous page
- 5 Access measured values menu
- 6 Access archives
- 7 Preview battery charging status

PROTECTIONS SETTING MENU



Vertical arrows allow scrolling between different electrical parameters:
li, lsd, tsd, lr, tr, lg, tg, etc.
Pressing horizontal icons gives access to corresponding windows allowing value settings. Each value can be increased/decreased, validated or suppressed.
The values need to be saved into memory at the end of the process, for each setting.

MEASURED VALUES MENU



This window allows previewing of measured values for:

- Currents
- Voltages (Ph/N and Ph/Ph)
- Active and reactive powers
- Power factor (total and per phase)
- Active and reactive energy
- Harmonics (for currents and voltages)

Pressing **I**, **m**, **M** and **avg** icons at the bottom of the window will display respectively: instantaneous, minimum, maximum and average value of electrical parameters.

Innovative & user friendly touch screen tripping units

CONTINUED

MP6 electronic protection units collect all the useful information in 5 sections, each one easily reachable via the main menu in order to allow an efficient control.

MP6 electronic protection units have an intuitive graphical interface. All useful information and selected settings are easy to understand and visible at a glance.

For example current values can be visualized on the starting page thanks to a histogram. Different other settings can be simultaneously displayed on the “settings” screen in order to have a global view.




MORE INFORMATION

- The following events and values are registered into memory and can be accessed via specific menu: cause of the last event, event counter, events history with date and hour, alarms history with date and hour

- The following events and values are registered into memory and can be accessed via specific menu: cause of the last event, event counter, events history with date and hour, alarms history with date and hour
 - MP6 tripping units allow following application: logical selectivity, management of non priority loads, contact management (with Cat.No 0 288 12)
 - MP6 tripping units allow following alarms: power reverse, current imbalance, maximum and minimum voltage values U1N, U2N, U3N, maximum currents I1, I2, I3, voltage imbalance (phase-neutral), inversed phase rotation, maximum and minimum frequency values.

Draw-out DMX³ frame 2500



Fast clipping control accessories

You can remotely control the DMX³ thanks to its range of accessories: shunt trips, undervoltage releases, motor operators and closing coils.

All the control accessories are simply clipped on to the front panel of the circuit breaker, which is especially configured in order to facilitate the clipping.

- Every type of accessory is compatible with its own location, in order to avoid any possible mistake.

All control accessories can be easily installed without any special tool and in a very short time. The installation is to be done on the front panel of the air circuit breaker. In that way, the separation between power and control circuits is guaranteed.

SHUNT TRIP

Shunt trips are devices used for the remote instantaneous opening of the air circuit breaker. They are generally controlled through an N/O type contact. The actual offer of shunt trips proposes different supply voltages from 24 V to 480 V compatibles with AC and DC currents. The shunt trips are already equipped with a special fast connector, to be directly inserted into auxiliary contacts block. An auxiliary contact is connected in series with the coil, cutting off its power supply when the main poles are open.



Shunt trip for DMX³ 2500
to 6200

	FOR DMX ³
Size	2500 to 6300
Rated operating voltage Vn	24 V ~ / \pm 48 V ~ / \pm 110 - 130 V ~ / \pm 220 - 250 V ~ / \pm 415 - 440 V \sim
Voltage range (% Vn)	70 to 110
Pick-up consumption (W/VA)	500/500
Pick-up time (ms)	180
Hold consumption (W/VA)	5/5
Opening time (ms)	30
Insulation voltage (kV)	2.5

UNDERVOLTAGE RELEASE

Undervoltage releases are devices which are generally controlled by an N/C type contact. The trigger instantaneous opening of the circuit breaker if their supply voltage drops below a certain threshold and in particular if the control contact opens. These releases are equipped with a device for limiting their consumption after the circuit has been closed.



Undervoltage release for
RMX3-2E00-tz / 200

FOR DMX³	
Size	2500 to 6300
Rated operating voltage Vn	24 V ~ / = 48 V ~ / = 110 - 130 V ~ / = 220 - 250 V ~ / = 415 - 440 V ~
Voltage range (% Vn)	85 to 110
Pick-up consumption (W/VA)	500/500
Pick-up time (ms)	180
Hold consumption (W/VA)	5/5
Opening time (ms)	60
Insulation voltage (kV)	2.5

CLOSING COILS

These coils are used for remotely controlling the closing of the power contacts of the circuit breaker. The springs of the circuit breaker are to be loaded prior to the action of the closing coils. They are controlled by an N/O type contact.



Closing coils for DMX³ 250
to 6200

	FOR DMX³
Size	2500 to 6300
Rated operating voltage Vn	24 V ~/ \pm 48 V ~/ \pm 110 - 130 V ~/ \pm 220 - 250 V ~/ \pm 415 - 440 V ~
Voltage range (% Vn)	85 to 110
Pick-up consumption (W/VA)	500/500
Pick-up time (ms)	180
Hold consumption (W/VA)	5/5
Opening time (ms)	50
Insulation voltage (kV)	2.5



**LEGRAND
ADVANTAGE**

Electrical connection is made in no time thanks to the fast connector supplied on all above accessories.



OTHER ELECTRICAL FEATURES

Number of control auxiliaries for DMX³ = 3
Shunt trip: 1
Undervoltage release: 1
Closing coils: 1

MOTOR OPERATORS

Motor operators, are used for remotely reloading the springs of the circuit breaker mechanism immediately after the device closes. The device can thus be re-closed almost immediately after an opening operation.

To motorise a DMX³ it is necessary to add a release coil (undervoltage release or shunt trip) and a closing coil.

If the supply voltage of the controls fails, it is still possible to reload the springs manually. Motor-driven controls have "limit switch" contacts which cut off the power supply of their motor after the springs have been reloaded. Motor operators are easy to mount, with only three screws.



Motor operator for DMX³ 25
to 6300

	FOR DMX³	
Size	2500 to 6300	
	50, 65 kA	100 kA
Rated operating voltage Vn	24 V $\sim/\!=$ 48 V $\sim/\!=$ 110 - 130 V $\sim/\!=$ 220 - 250 V $\sim/\!=$ 415 - 440 V \sim 480 V \sim	
Voltage range (% Vn)	85 to 110	
Max. power consumption (W/Vn)	180/180	240/240
Max. peak current for about 80 ms	2 to 3 x In	
Charging time [s]	5	7
Operating frequency [°/min]	2	1

SAFETY AND PADLOCKING ACCESSORIES FOR AN INCREASED SECURITY

The DMX³ circuit breakers draw-out types are delivered as standard with safety padlocking shutters preventing access to live terminals. They have a number of other safety devices, such as:

- Key-operated locks:
 - Main contacts open
 - Circuit breaker in draw-out position
 - Padlocks for:
 - Main contacts open
 - Contact shutters closed (for draw-out position)
 - Door locking in order to prevent the opening of the electrical switchboard door when the contacts of the ACB are closed.




Fixed version equipped
with padlocking system



Draw-out version equipped
with key-operated locks

FRONT PANEL CONNECTION TERMINAL BLOCK

The terminal block of DMX³ ACBs offers the possibility to connect a trip contact, up to 10 auxiliary contacts (up to 6 contacts for DMX³ 1600) and different other control and signalling functions



Easy identification of control accessories

Electrical auxiliaries are connected on the front panel on terminal blocks provided for this purpose. Accessories are identified on the front panel.

As the cover has window, it is easy to ascertain, which devices are fitted on the circuit breaker.



MORE INFORMATION

	DMX³ 2500	DMX³ 4000	DMX³ 6300
External auxiliary power supply		0 288 06	
Programmable contact module		0 288 12	
Communication option		0 288 05	
External neutral	0 288 11		0 288 10

FIXED VERSION-CHOOSE YOUR CONNECTION ACCESSORIES: 3 POSSIBILITIES

The type of rear terminals can be easily changed according to your needs.



The breaker is supplied with rear terminals for horizontal connection

Connection: maximum adaptability **DMX³ 2500 to 6300**

REAR TERMINALS FOR FLAT CONNECTION



Frame 2500:

3P: Cat. N° 0 288 84
4P: Cat. N° 0 288 85


Frame 4000:

3P: Cat. N° 0 288 92
4P: Cat. N° 0 288 93

Frame 6300:

3P: Cat. N° 0 288 92 x 2
4P: Cat. N° 0 288 93 x 2

FIXED VERSION: EXAMPLES OF CONNECTIONS



REAR TERMINALS FOR VERTICAL CONNECTION

This type of connection uses 2 accessories: the previous rear terminals for flat connection, which must be equipped with the vertical ones.




Frame 1:

3P: Cat. N° 0 288 84 + 0 288 82
4P: Cat. N° 0 288 85 + 0 288 83

Frame 2 and 3⁽¹⁾:

3P: Cat. N° 0 288 92 + 0 288 94
4P: Cat. N° 0 288 93 + 0 288 95

(1) For frame 6300 the quantity is multiplied by 2



SPREADERS

For any situation requiring a bigger width for a safe connection (i.e. aluminium bus bars).

Frame 2500:

3 types of accessories



Flat connection


3P: Cat. N° 0 288 86
4P: Cat. N° 0 288 87

Vertical connection

3P: Cat. N° 0 288 88
4P: Cat. N° 0 288 89

Horizontal connection

3P: Cat. N° 0 288 90
4P: Cat. N° 0 288 91



The fixed version of DMX³ is equipped with rear terminals for horizontal connection with bars.

You can change connection type according to your needs.



DRAW-OUT VERSION-CHOOSE YOUR CONNECTION ACCESSORIES

Draw-out version of the DMX³ breakers is supplied with rear terminals for flat connection with bars. You can easily transform those terminals into vertical or horizontal type by using the unique reversible connector.



The breaker is supplied with rear terminals for flat connection

2 TYPES OF FIXING

Reversible connector for vertical or horizontal connection.

**Frame 2500:**

3P: Cat. N° 0 288 96
4P: Cat. N° 0 288 97

Frame 4000:








3P: Cat. N° 0 288 94
4P: Cat. N° 0 288 95

Frame 6300:

3P: Cat. N° 0 288 94 x 2
4P: Cat. N° 0 288 95 x 2

DRAW-OUT VERSION: EXAMPLES OF CONNECTIONS

Draw-out version of the DMX³ breakers is supplied with rear terminals for flat connection with bars. You can easily transform the rear terminals into vertical or horizontal type by using the unique reversible connector.

**FLAT CONNECTION USING THE REAR TERMINALS OF THE BREAKER**

Connection: maximum adaptability **DMX³ 2500 to 6300** CONTINUED


The draw-out version is equipped with rear terminals for flat connection with bars.

**CONNECTIONS: A FEW RECOMMENDATIONS!**

- Connections provide the electrical connection of equipment and are also responsible for a considerable proportion of their heat dissipation.
- Connections must never be under-sized.
- Plates or terminals must be used over a maximum area.

- Heat dissipation is encouraged by arranging the bars vertically. If an uneven number of bars is connected, place the higher number of bars on the upper part of the terminal.
- Avoid bars running side by side: this causes poor heat dissipation and vibrations.
- Place spacers between the bars to maintain a distance between them which is at least equivalent to their thickness.

Automatic transfer switches



Touch-sensitive buttons
for programming the
various operating
parameters directly on
the control unit

The optical communication port on the front can take a USB or a Wi-Fi connection module, which allows communication with a computer, smartphone or a tablet for programming, diagnostics and data downloading, without having to cut off the power to the electrical panel.


Continuity of service & increased safety

Automatic transfer switches answer the double need of continuity of service and greater safety (security). Traditionally used in hospitals, public buildings, industries with continuous manufacturing

processes, airports and military applications, automatic transfer switches become increasingly required for new applications such as telecommunications and computing treatment or in the management of


energy sources, notably those say “renewable energies”. Our range of control units includes 3 different types, depending on the desired service level.

STANDARD UNIT



2 circuit breakers
(Cat.No 4 226 80)

CONFIGURABLE UNIT




2 circuit breakers
(Cat.No 4 226 82)




USB modul





DMX³ 1600

Horizontal configuration


Configuration N° 1


 Required cable length:
 $L = 620 + H$

Vertical configuration



Configuration N° 2

 Required cable length:
 $L = 950 + V$

Vertical + Horizontal configuration



Configuration N° 3
 Required cable length:
 $L = 620 + V + H$
DMX³ 2500 / 4000 / 6300

Horizontal configuration


Configuration N° 1


 Required cable length:
 $L = 1430 + H$

Vertical configuration


Configuration N° 2

 Required cable length:
 $L = 1570 + V$

Vertical + Horizontal configuration


Configuration N° 3
 Required cable length:
 $L = 1430 + V + H$


Transfer switching & interlocking

Mechanical interlock is set up using cables and a mechanical interlock device and can interlock 2 or 3 devices, which may be different type in a vertical or horizontal configuration.

The interlock device is mounted on the right-hand side of the air circuit breaker.

EXAMPLES OF CABLE INTERLOCK SELECTION FOR 2 OR 3 AIR CIRCUIT BREAKERS
**DMX³ 2500 / 4000 / 6300 [3 ACBs]
 Configuration N° 3: $L = 1430 + H + V$**

Distance between air circuit breakers	Horizontal (mm)				
	725	1 000	1 450	2 000	
Vertical (mm)	800	0 289 21	0 289 22	0 289 23	0 289 24
	1 000	0 289 22	0 289 22	0 289 23	0 289 24
	1 600	0 289 23	0 289 24	0 289 24	0 289 25
	2 000	0 289 24	0 289 24	0 289 25	0 289 25

CABLE LENGTH

Cat.Nos	0 289 17	0 289 18	0 289 20	0 289 21	0 289 22	0 289 23	0 289 24	0 289 25
Length (mm)	1 000	1 500	2 600	3 000	3 600	4 000	4 600	5 600

an XL³ S 4000 enclosure




DMX³ 6300 inside
an XL³ 6300 enclosure

DMX³ FIXED VERSION




DMX³ size 2500



DMX³ DRAW-OUT VERSION



DMX3 size 2500



Be free to choose XL³ fully adaptable enclosure

It is very easy to create the configuration you want thanks to the different available sizes of XL³ S 4000 or XL³ 4000 and 6300 enclosures.

- A full range of accessories, such as dedicated fixing plates and faceplates, facilitate the integration of DMX³ devices inside the enclosures.

XLPro³ software let you choose the optimum configuration between XL and XL³ S, according to the size and the requirements of your installation.



Mounting Principle

In XL³ and XL³ S, the DMX³ devices and the associated busbars are arranged according to an identical principle for power ratings up to 4 000 A, that is, the possibility of mounting two devices per enclosure.

The installation height of DMX³ units is always 600 mm whatever the type and size of the device. When 2 DMX³ devices are installed in the same cell, this leaves at least a useful 600 mm for running the busbars.

Air circuit breakers DMX³ 2500 and 4000

from 800 to 4000 A



0 286 56 + 0 288 02 (p. 161)



0 286 74 + 0 288 02 (p. 161)



0 287 56 + 0 288 02 (p. 161)

Dimensions p. 42-45
Electrical characteristics p. 47-49

Automatic air circuit breakers must be equipped with electronic protection unit (p. 161), imperatively ordered together for factory assembly
Please ask for DMX³ order form
Conform to IEC 60947-2

	Pack	Cat.Nos	Fixed version
			Supplied with: - 4 auxiliary contacts: NO/NC - rear terminals for horizontal connection with bars - door sealing
			DMX³ - N 2500
			Breaking capacity Icu 50 kA (415 V \sim)
			Frame 2500
			3P 4P
	1	0 286 21	0 286 31
	1	0 286 22	0 286 32
	1	0 286 23	0 286 33
	1	0 286 24	0 286 34
	1	0 286 25	0 286 35
	1	0 286 26	0 286 36
			800 1000 1250 1600 2000 2500
			DMX³ - H 2500
			Breaking capacity Icu 65 kA (415 V \sim)
			Frame 2500
			3P 4P
	1	0 286 41	0 286 51
	1	0 286 42	0 286 52
	1	0 286 43	0 286 53
	1	0 286 44	0 286 54
	1	0 286 45	0 286 55
	1	0 286 46	0 286 56
			800 1000 1250 1600 2000 2500
			DMX³ - L 2500
			Breaking capacity Icu 100 kA (415 V \sim)
			Frame 2500
			3P 4P
	1	0 286 61	0 286 71
	1	0 286 62	0 286 72
	1	0 286 63	0 286 73
	1	0 286 64	0 286 74
	1	0 286 65	0 286 75
	1	0 286 66	0 286 76
			800 1000 1250 1600 2000 2500
			DMX³ - N 4000
			Breaking capacity Icu 50 kA (415 V \sim)
			Frame 4000
			3P 4P
	1	0 286 27	0 286 37
	1	0 286 28	0 286 38
			3200 4000
			DMX³ - H 4000
			Breaking capacity Icu 65 kA (415 V \sim)
			Frame 4000
			3P 4P
	1	0 286 47	0 286 57
	1	0 286 48	0 286 58
			3200 4000
			DMX³ - L 4000
			Breaking capacity Icu 100 kA (415 V \sim)
			Frame 4000
			3P 4P
	1	0 286 67	0 286 77
	1	0 286 68	0 286 78
			3200 4000

	Pack	Cat.Nos	Draw-out version
			Supplied with: - 4 auxiliary contacts: NO/NC - draw-out base and kit - flat rear terminals for connection with bars - door sealing
			DMX³ - N 2500
			Breaking capacity Icu 50 kA (415 VA)
			Frame 2500
			3P 4P
	1	0 287 21	0 287 31
	1	0 287 22	0 287 32
	1	0 287 23	0 287 33
	1	0 287 24	0 287 34
	1	0 287 25	0 287 35
	1	0 287 26	0 287 36
			800 1000 1250 1600 2000 2500
			DMX³ - H 2500
			Breaking capacity Icu 65 kA (415 VA)
			Frame 2500
			3P 4P
	1	0 287 41	0 287 51
	1	0 287 42	0 287 52
	1	0 287 43	0 287 53
	1	0 287 44	0 287 54
	1	0 287 45	0 287 55
	1	0 287 46	0 287 56
			800 1000 1250 1600 2000 2500
			DMX³ - L 2500
			Breaking capacity Icu 100 kA (415 VA)
			Frame 4000
			3P 4P
	1	0 287 61	0 287 71
	1	0 287 62	0 287 72
	1	0 287 63	0 287 73
	1	0 287 64	0 287 74
	1	0 287 65	0 287 75
	1	0 287 66	0 287 76
			800 1000 1250 1600 2000 2500
			DMX³ - N 4000
			Breaking capacity Icu 50 kA (415 V \sim)
			Frame 4000
			3P 4P
	1	0 287 27	0 287 37
	1	0 287 28	0 287 38
			3200 4000
			DMX³ - H 4000
			Breaking capacity Icu 65 kA (415 V \sim)
			Frame 4000
			3P 4P
	1	0 287 47	0 287 57
	1	0 287 48	0 287 58
			3200 4000
			DMX³ - L 4000
			Breaking capacity Icu 100 kA (415 V \sim)
			Frame 4000
			3P 4P
	1	0 287 67	0 287 77
	1	0 287 68	0 287 78
			3200 4000

Air circuit breakers DMX³ 6300

5000 and 6300 A



0 289 51 + 0 288 02

Dimensions p. 46
Electrical characteristics p. 47-49

Automatic air circuit breakers must be equipped with electronic protection unit, imperatively ordered together for factory assembly
Please ask for DMX³ order form
Conform to IEC 60947-2

Electronic protection units for DMX³ 2500, 4000 and 6300



0 288 02


Settings and curves p. 47

DMX³ circuit breakers must be equipped with electronic protection units (to be ordered together for factory assembly) enabling very precise adjustments of the protection conditions, while maintaining total discrimination with downstream devices
All protection units are equipped with batteries for powering in case of mains fault or when the breaker is open or not connected


MP4 protection units with LCD screen

Integrated LCD screen for displaying electrical values, settings and log
Adjustment via selector switches


Pack	Cat.Nos	LI protection unit
1	0 288 00	Adjustment of: I _r , I _{lr} , I _{tr}



Pack	Cat.Nos	LSI protection unit
1	0 288 01	Adjustment of: I _{sd} , I _{tsd} , I _{lr} , I _{tr} and I _i



Pack	Cat.Nos	LSig protection unit
1	0 288 02	Adjustment of: I _{sd} , I _{tsd} , I _{lr} , I _{tr} , I _i , I _{lg} and I _{tg}



Pack	Cat.Nos	MP6 touch screen protection units
1	0 288 03	Measure and display instantaneous, maximum and average values of different electrical values and protection conditions Fault signalling and log



Pack	Cat.Nos	LSi protection unit
1	0 288 04	Adjustment of: I _{sd} , I _{tsd} , I _{lr} , I _{tr} and I _i



1: Optional accessories, to be ordered when ordering electronic protection unit and DMX³ air circuit breakers for factory assembly

Trip free switches DMX³-I

from 1250 to 6300 A



0 286 96

0 287 96

Dimensions p. 42-46

Conform to IEC 60947-3

Pack	Cat.Nos	Fixed version
		Supplied with: - 4 auxiliary contacts: NO/NC - flat rear terminals for connection with bars - door sealing
		DMX³-I 2500
1	0 286 83 0 286 93	Frame 2500 3P 4P In(A) 1250
1	0 286 84 0 286 94	1600
1	0 286 85 0 286 95	2000
1	0 286 86 0 286 96	2500
		DMX³-I 4000
1	0 286 87 0 286 97	Frame 4000 3P 4P In(A) 3200
1	0 286 88 0 286 98	4000
		DMX³-I 6300
1	0 289 70 0 289 71	Frame 6300 3P 4P In(A) 6300

Draw-out version

Pack	Cat.Nos	Draw-out version
		Supplied with: - 4 auxiliary contacts: NO/NC - draw-out base and kit - flat rear terminals for connection with bars - door sealing
		DMX³-I 2500
1	0 287 83 0 287 93	Frame 2500 3P 4P In(A) 1250
1	0 287 84 0 287 94	1600
1	0 287 85 0 287 95	2000
1	0 287 86 0 287 96	2500
		DMX³-I 4000
1	0 287 87 0 287 97	Frame 4000 3P 4P In(A) 3200
1	0 287 88 0 287 98	4000
		DMX³-I 6300
1	0 289 77 0 289 78	Frame 6300 3P 4P In(A) 6300

Trip free switches DMX³-I

from 1250 to 6300 A

Technical characteristics										
Trip free switch DMX ³ -I			2500	4000	6300					
Frame			2500	4000	6300					
Rating In (A)			1250 1600 2000 2500	3200 4000	6300					
Rated insulation voltage Ui (V)			1000	1000	1000					
Rated impulse withstand voltage Uimp (kV)			12	12	12					
Rated operational voltage (50/60Hz) Ue (V)			690	690	690					
Isolation behaviour			Yes	Yes	Yes					
Short-circuit making capacity Icm (kA)			230 V~ 415 V~ 500 V~ 600 V~ 690 V~	143 143 143 132 121	220 220 220 165 143					
Short time withstand current Icw (kA) for t = 1 s			230 V~ 415 V~ 500 V~ 600 V~ 690 V~	65 65 65 60 55	85 85 100 75 65					
Endurance (cycles) with Maintenance			mechanical	20000	20000	10000				
Endurance (cycles) without Maintenance			mechanical	10000	10000	10000				
			Electrical	10000	10000	5000				

Temperature derating									
Fixed version									
	Temperature								
	40°C	50°C	60°C	65°C	70°C	Imax (A)	Ir / In	Imax (A)	Ir / In
DMX ³ -I 2500	1250	1	1250	1	1250	1	1250	1	1250
	1600	1	1600	1	1600	1	1600	1	1600
	2000	1	2000	1	1960	0.98	1920	0.96	1880
	2500	1	2500	1	2350	0.94	2250	0.9	2150
DMX ³ -I 4000	3200	1	3200	1	3200	1	3136	0.98	3008
	4000	1	4000	1	3680	0.92	3440	0.86	3120
DMX ³ -I 6300	6300	1	6300	1	6048	0.96	5796	0.92	5544

Temperature derating									
Draw-out version									
	Temperature								
	40°C	50°C	60°C	65°C	70°C	Imax (A)	Ir / In	Imax (A)	Ir / In
DMX ³ -I 2500	1250	1	1250	1	1250	1	1250	1	1250
	1600	1	1600	1	1600	1	1600	1	1600
	2000	1	2000	1	1960	0.98	1920	0.96	1875
	2500	1	2400	0.96	2250	0.9	2100	0.84	1950
DMX ³ -I 4000	3200	1	3200	1	3200	1	3072	0.96	2880
	4000	1	3760	0.94	3440	0.86	3200	0.8	2960
DMX ³ -I 6300	6300	1	6174	0.98	5985	0.95	5796	0.92	5292

Auxiliaries and accessories for DMX³ 2500, 4000 and 6300



Control and signalling auxiliaries


Pack	Cat.Nos	Shunt trip
1	0 288 48	When energised the circuit breaker will be tripped
1	0 288 49	24 V~/=
1	0 288 50	48 V~/=
1	0 288 51	110 - 130 V~/=
1	0 288 52	220 - 250 V~/=
		415 - 480 V~

Pack	Cat.Nos	Undervoltage releases
1	0 288 55	When the coil is de-energised, the circuit breaker will be tripped
1	0 288 56	24 V~/=
1	0 288 57	48 V~/=
1	0 288 58	110 - 130 V~/=
1	0 288 59	220 - 250 V~/=
		415 - 480 V~

Pack	Cat.Nos	Module for delayed tripping

<tbl_r cells="3" ix="

Rear terminals for DMX³ 2500, 4000 and 6300



Dimensions p. 42-46

Pack	Cat.Nos		Rear terminals
1	3P 0 288 84	4P 0 288 85	For DMX³ frame 2500 fixed version For flat connection with bars To be fixed onto horizontal rear terminals of the circuit breaker
1	0 288 82	0 288 83	For vertical connection with bars Those terminals are used in order to transform a flat connection into a vertical one To be fixed onto Cat.Nos 0 288 84/85 according to the number of poles
1	0 288 96	0 288 97	For DMX³ frame 2500 draw-out version For vertical or horizontal connection with bars To be fixed onto plate rear terminals of the circuit breaker
1	0 288 92	0 288 93	For DMX³ frame 4000 and 6300 fixed version For flat connection with bars To be fixed onto horizontal rear terminals of the circuit breaker 2 sets are required for frame 6300
1	0 288 94	0 288 95	For DMX³ frame 4000 and 6300 fixed or draw-out version On DMX ³ fixed version: - For vertical connection with bars - To be fixed onto Cat.Nos 0 288 92/93 according to the number of poles On DMX ³ draw-out version: - For vertical or horizontal connection with bars - To be fixed directly onto plate rear terminals of the circuit breaker 2 sets are required for frame 6300

Spreaders for DMX³ frame 2500 fixed version

1	3P 0 288 86	4P 0 288 87
1	0 288 88	0 288 89
1	0 288 90	0 288 91

Insulation shields

1	3P 0 288 98	4P 0 288 99
1	0 288 18	0 288 19

Equipment for DMX³ 2500, 4000 and 6300 transfer switches



0 288 64

Technical characteristics p. 50

Equipment for transfer switches

The mechanical interlock is set up using cables and can interlock 2 or 3 devices, which may be different type in a vertical or horizontal configuration. The interlock unit is mounted on the right-hand side of the device. Cable interlock to be ordered separately (cable length to be specified according to every configuration - see below). Interlock for DMX³ frame 2500. Interlock for DMX³ frame 4000. Interlock for DMX³ frame 6300.

Cable interlock

Length
1000 mm
1500 mm
2600 mm
3000 mm
3600 mm
4000 mm
4600 mm
5600 mm

Automatic transfer switch control units



Technical characteristics p. 50
Configuration software see e-catalogue

They can control transfer switching between two sources, manage generator start/stop, control single phase, two-phase and three-phase networks, control phase-phase and phase-neutral voltages.

For DPX³ and DMX³ circuit breakers and CTX³ contactors

Automatic transfer switch control units

Pack	Cat.Nos	Automatic transfer switch control units
1	4 226 80	For standard management of 2 circuit breakers 6 programmable digital inputs and 6 programmable relay outputs Digital display Power supply: 12...48 V _{DC} IP54
1	4 226 82 ¹	For advanced management of 2 circuit breakers 6 programmable digital inputs and 7 programmable relay outputs Can be equipped with maximum 2 plug-in modules between: - extension modules Cat.No 4 226 90/91/92 - opto-isolated RS485 communication interface Cat.No 4 226 89 LCD display IR communication port on the front panel for connection of USB or WiFi modules Cat.No 4 226 87/88
1	4 226 83 ¹	Can be configured with the help of front panel touch keys or of the Legrand dedicated software Power supply: 12-24 V _{DC} ; 110-240 V _{AC} IP40 For advanced management of 3 circuit breakers 8 programmable digital inputs and 7 programmable relay outputs Can be equipped with maximum 3 plug-in extension modules between Cat.No 4 226 90/91/92 Integrated opto-isolated RS485 communication interface LCD display IR communication port on the front panel for connection of USB or WiFi modules Cat.No 4 226 87/88

Dual power supply selector

Dual power supply selector measures and controls two supply voltages at its inputs (single phase, 230 V_{AC}) and selects the most adapted voltage for auxiliary circuits supply. Equipped with 1 alarm contact, if no supply voltage can be selected within the limits.

Plug-in modules

Opto-isolated RS485 interface
4 opto-isolated static outputs
2 relay outputs, rated 5 A 250 V_{AC}
2 opto-isolated digital inputs and 2 relay outputs rated 5 A 250 V_{AC}

Communication accessories

These communication devices can be used to connect Alptec 8 and Alptec 3.2/5.2/8.2 power factor controllers and automatic transfer switch controllers to a computer; smartphone or tablet. For programming, downloading data, diagnostics and upgrading the firmware.

USB front connector

Computer connection cable with USB connector. The computer identifies the connection as a standard USB connection. There is no need to switch off the controller power supply.

¹: Configuration software available for download via E-catalogue

Transfer switching technical guide available for download on www.docexport.legrand.com




DMX³ 2500 and DMX³-I 2500 - frame 2500

dimensions



Fixed version - frame 2500

Overall dimensions

3P version





4P version




A = fixing point on plate of enclosure

Connection principle




Rear terminals for vertical connection with bars

Cat.Nos 0 288 82/83





Rear terminals for horizontal connection with bars

3P version




4P version




Spreaders for flat connection with bars

Cat.Nos 0 288 86/87




Spreaders for vertical connection with bars

Cat.Nos 0 288 88/89



Spreaders for horizontal connection with bars


Cat.Nos 0 288 90/91





Draw-out version - frame 2500

Overall dimensions

3P version




4P version





Rear terminals for flat connection with bars

3P version




4P version





Rear terminals for horizontal connection with bars - Cat.Nos 0 288 96/97

3P version




4P version








Rear terminals for vertical connection with bars - Cat.Nos 0 288 96/97

3P version



4P version




DMX³ 2500, DMX³-I 2500, DMX³ 4000 and DMX³-I 4000 - frame 4000

dimensions



Fixed version - frame 4000

Overall dimensions



3P version




4P version





A = fixing point on plate of enclosure

Connection principle**Rear terminals**

3P version




4P version


**Draw-out version - frame 4000**

Overall dimensions

3P version



4P version




A = fixing point on plate of enclosure


Draw-out version - frame 4000 (continued)

Rear terminals for flat connection with bars

3P version




4P version





Rear terminals for horizontal connection with bars

Cat.Nos 0 288 92/93

3P version




4P version





Rear terminals for vertical connection with bars

Cat.Nos 0 288 92/93

3P version





4P version





DMX³ 6300 et DMX³-I 6300 - frame 6300

taille 3

■ Fixed version - frame 6300



■ Draw-out version - frame 6300


DMX³

electronic protection units

■ Settings of the electronic protection units

MP4 LI

Ir, tr, li, adjustment on front panel



• Long time delay protection against overloads

Ir from 0.4 to 1 x In (6 + 6 steps) on two selectors (0.4 <= 0.9, by steps of 0.1 and 0.0 <= 0.1, by steps of 0.02)

• Long delay protection operation time

tr - at 6 x Ir (4 + 4 steps)
tr = 5-10-20-30 s (MEM ON) 30-20-10-5 s (MEM OFF)

• Short delay protection against short-circuits

Fixed threshold:

Isd = 10 x Ir

tsd = 1s


• Instantaneous protection against very high short circuits

li from 2 to 15 x In or lcw (9 steps) li = 2-3-4-5-6-8-10-12-15 x In or lcw

• Neutral protection: In = OFF - 50% - 100% - 100%

MP4 LSI

Ir, tr, lsd, tsd, li adjustment on front panel



• Long time delay protection against overloads

Ir from 0.4 to 1 x In (6 + 6 steps) on two selectors (0.4 <= 0.9, by steps of 0.1 and 0.0 <= 0.1, by steps of 0.02)

• Long delay protection operation time

tr - at 6 x Ir (4 + 4 steps) tr = 5-10-20-30 s (MEM ON) 30-20-10-5 s (MEM OFF)

• Short time delay protection against short circuits

Isd from 1.5 to 10 x Ir (9 steps) lsd = 1.5-2-2.5-3-4-5-6-8-10 x Ir
tsd from 0 to 0.3 s (4 + 4 steps) tsd = 0-0.1-0.2-0.3 s (t=cost), 0.3-0.2-0.1-0.01 s (l2t=cost)


• Instantaneous protection against very high short circuits

li from 2 to 15 x In or lcw (9 steps) li=off-2-3-4-6-8-10-12-15 x In or lcw

• Neutral protection: In = OFF - 50% - 100% - 100%

MP4 LSig

Ir, tr, li, lg, tg, lsd, tsd, adjustment on front panel



• Long time delay protection against overloads

Ir from 0.4 to 1 x In (6 + 6 steps) on two selectors (0.4 <= 0.9, by steps of 0.1 and 0.0 <= 0.1, by steps of 0.02)

• Long delay protection operation time

tr - at 6 x Ir (4 + 4 steps) tr = 5-10-20-30 s (MEM ON) 30-20-10-5 s (MEM OFF)

• Short time delay protection against short circuits

Isd from 1.5 to 10 x Ir (9 steps) lsd = 1.5-2-2.5-3-4-5-6-8-10 x Ir
tsd from 0 to 0.3 s (4 + 4 steps) tsd = 0-0.1-0.2-0.3 s (t=cost), 0.3-0.2-0.1-0.001 s (l2t=cost)

• Instantaneous protection against very high short circuits

li from 2 to 15 x In or lcw (9 steps) li = 2-3-4-6-8-10-12-15 x In or lcw

• Earth fault current

lg from 0.2 to 1 x In (9 steps) lg = 0.2-0.3-0.5-0.6-0.7-0.8-1 x In : OFF
tg from 0.1 + 1 s (4 steps) tg = 0.1-0.2-0.5-1 s (both t = const and l2t = const)

• Neutral protection: In = OFF - 50% - 100% - 100%

■ Selectivity in three-phase network 415 V~

DMX³/DPX³

Downstream	Upstream	DMX ³ 2500						DMX ³ 4000	DMX ³ 6300
		800 A	1000 A	1250 A	1600 A	2000 & 2500 A	3200 & 4000 A	5000 & 6300 A	
DPX ³ 160 ⁽¹⁾	T	T	T	T	T	T	T	T	
DPX ³ 250 ⁽¹⁾	T	T	T	T	T	T	T	T	
DPX ³ 630 ⁽¹⁾ TM and elec.	T	T	T	T	T	T	T	T	
630 A	T	T	T	T	T	T	T	T	
DPX ³ 1600 ⁽¹⁾ thermal magnetic	800 A								
1000 A									
1250 A									
630 A									
800 A									
1000 A									
1250 A									
1600 A									

1: All breaking capacities

T: total selectivity, up to downstream circuit breaker breaking capacity according to IEC 60947-2

DMX³/DMX³

Downstream	Upstream	DMX ³								
		800 A	1000 A	1250 A	1600 A	2000 A	2500 A	3200 A	4000 A	5000 A
800 A		T	T	T	T	T	T	T	T	T
1000 A			T	T	T	T	T	T	T	T
1250 A				T	T	T	T	T	T	T
1600 A					T	T	T	T	T	T
2000 A						T	T	T	T	T
2500 A							T	T	T	T
3200 A								T	T	T
4000 A									T	T
5000 A										T
6300 A										

T: total selectivity, up to downstream circuit breaker breaking capacity according to IEC 60947-2

lcu of downstream circuit breaker <= lcu of upstream circuit breaker

Selectivity values are intended with protection unit properly adjusted

DMX³/DX³

	DMX ³ 2500						DMX ³ 4000	DMX ³ 6300		
	630 A	800 A	1000 A	1250 A	1600 A	2000 A	2500 A	3200 A	4000 A	5000 A
DX ³ 6000 - 10 kA	T	T	T	T	T	T	T	T	T	T
DX ³ 10000 - 16 kA	T	T	T	T	T	T	T	T	T	T
DX ³ 25 kA	T	T	T	T	T	T	T	T	T	T
DX ³ 36 kA	T	T	T	T	T	T	T	T	T	T
DX ³ 50 kA	T	T	T	T	T	T	T	T	T	T

T: total selectivity, up to downstream circuit breaker breaking capacity according to IEC 60947-2

DMX³ tripping curves,
see technical sheet

For the settings of MP6 protection units
Please, consult us

DMX³

technical characteristics (continued)

Technical characteristics

DMX³ 2500

DMX ³ according to IEC 60947-2	DMX ³ 2500																		
	800			1000			1250			1600			2000			2500			
	N	H	L	N	H	L	N	H	L	N	H	L	N	H	L	N	H	L	
Number of poles	3P - 4P			3P - 4P			3P - 4P			3P - 4P			3P - 4P			3P - 4P			
Rating In (A)	800			1000			1250			1600			2000			2500			
Rated insulation voltage Ui (V)	1000			1000			1000			1000			1000			1000			
Rated impulse withstand voltage Uimp (kV)	12			12			12			12			12			12			
Rated operational voltage (50/60Hz) Ue (V)	690			690			690			690			690			690			
Frame	2500			4000			2500			4000			2500			4000			
230 V~	50	65	100	50	65	100	50	65	100	50	65	100	50	65	100	50	65	100	
415 V~	50	65	100	50	65	100	50	65	100	50	65	100	50	65	100	50	65	100	
500 V~	50	65	100	50	65	100	50	65	100	50	65	100	50	65	100	50	65	100	
600 V~	50	60	75	50	60	75	50	60	75	50	60	75	50	60	75	50	60	75	
690 V~	50	55	65	50	55	65	50	55	65	50	55	65	50	55	65	50	55	65	
Service breaking capacity Ics (% Icu)	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	100	
230 V~	105	143	220	105	143	220	105	143	220	105	143	220	105	143	220	105	143	220	
415 V~	105	143	220	105	143	220	105	143	220	105	143	220	105	143	220	105	143	220	
500 V~	105	143	220	105	143	220	105	143	220	105	143	220	105	143	220	105	143	220	
600 V~	105	132	165	105	132	165	105	132	165	105	132	165	105	132	165	105	132	165	
690 V~	105	121	143	105	121	143	105	121	143	105	121	143	105	121	143	105	121	143	
Short-circuit making capacity Icm (kA)	230 V~	50	65	85	50	65	85	50	65	85	50	65	85	50	65	85	50	65	85
415 V~	50	65	85	50	65	85	50	65	85	50	65	85	50	65	85	50	65	85	
500 V~	50	65	85	50	65	85	50	65	85	50	65	85	50	65	85	50	65	85	
600 V~	50	60	75	50	60	75	50	60	75	50	60	75	50	60	75	50	60	75	
690 V~	50	55	65	50	55	65	50	55	65	50	55	65	50	55	65	50	55	65	
Category of use	B			B			B			B			B			B			
Isolation behavior	Yes			Yes			Yes			Yes			Yes			Yes			
Endurance (cycles) with maintenance	mechanical	20000			20000			20000			20000			20000			20000		
Endurance (cycles) without maintenance	mechanical	10000			10000			10000			10000			10000			10000		
Endurance (cycles) electrical	electrical	10000			10000			10000			10000			10000			10000		


DMX³ 4000

DMX ³ according to IEC 60947-2	DMX ³ 4000					
	3200		4000			
	N	H	L	N	H	L
Number of poles	3P - 4P		3P - 4P			
Rating In (A)	3200		4000			
Rated insulation voltage Ui (V)	1000		1000			
Rated impulse withstand voltage Uimp (kV)	12		12			
Rated operational voltage (50/60Hz) Ue (V)	690		690			
Frame	4000		4000			
230 V~	50	65	100	50	65	100
415 V~	50	65	100	50	65	100
500 V~	50	65	100	50	65	100
600 V~	50	60	75	50	60	75
690 V~	50	55	65	50	55	65
Service breaking capacity Ics (% Icu)	100	100	100	100	100	100
230 V~	105	143	220	105	143	220
415 V~	105	143	220	105	143	220
500 V~	105	143	220	105	143	220
600 V~	105	132	165	105	132	165
690 V~	105	121				


Supply invertors equipment for DMX³ 2500, 4000 and 6300

Installation principle

Mounting of interlock unit



Choice of cable interlock



Automation control units for transfer switches


Technical characteristics and dimensions

Technical characteristics

	Cat.Nos		
	4 226 80	4 226 82	4 226 83
Voltage inputs	Ue max rated voltage 50-576 V~ (L-L)	480 V~ L-L (277 V~ L-N)	100-480 V~ 600 V~ L-L (346 V~ L-N)
	Measuring range	50-576 V~ (L-L)	50-576 V~ L-L 50...720 V L-L
	Primary voltage VT max	-	50000 V
	Frequency range	45...66 Hz	45...65 Hz - 360...440 Hz
	Measurement type	True RMS value	True RMS value
	Connection modes	Single phase, two-phase or three- phase system	Single phase, two-phase or three- phase system with or without neutral
	Measuring error	± 0.25% f.s. ± 1 digit	± 0.25% f.s. ± 1 digit
Ambient condition	Operating temperature -30...+80 °C	-20...+60 °C -30...+70 °C	-30...+70 °C
	Storage temperature -30...+80 °C	-30...+80 °C	-30...+80 °C
	Relativity humidity < 90 %	80 % (IEC/EN 60068- 2-78)	80 % (IEC/EN 60068- 2-78)
	Maximum pollution degree 3	2	2
	Overtoltage category 3	3	3
	Measurement category II	II	II
	Rated impulse withstand voltage Uimp 4.0 kV	Uimp 7.3 kV	Uimp 7.3 kV


Dimensions (continued)

Cat.No 4 226 82




Dimensions


Cat.No 4 226 86



Cat.No 4 226 80




Door cut



Catalogue number index

Cat.Nos	Page N°	Pack	Cat.Nos	Page N°	Pack												
0 280 00																	
0 280 00	28	1	0 281 26	30	1	0 286 33	32	1	0 287 34	32	1	0 288 15	35	1	0 289 00		
01	-	1	27	-	1	34	-	1	35	-	1	16	-	1	0 289 02	35	1
02	-	1	28	-	1	35	-	1	36	-	1	18	36	1	03	-	1
03	-	1	29	-	1	36	-	1	37	-	1	19	-	1	04	-	1
04	-	1	30	-	1	37	-	1	38	-	1	20	35	1	05	-	1
06	-	1	31	-	1	38	-	1	41	-	1	21	-	1	09	-	1
07	-	1	32	-	1	41	-	1	42	-	1	23	-	1	10	-	1
08	-	1	33	-	1	42	-	1	43	-	1	24	-	1	11	-	1
09	-	1	34	-	1	43	-	1	44	-	1	25	-	1	12	-	1
10	-	1	35	-	1	44	-	1	45	-	1	26	-	1	13	-	1
24	-	1	36	-	1	45	-	1	46	-	1	28	-	1	14	-	1
25	-	1	37	-	1	46	-	1	47	-	1	29	-	1	15	-	1
26	-	1	38	-	1	47	-	1	48	-	1	30	-	1	16	-	1
27	-	1	39	-	1	48	-	1	51	-	1	31	-	1	17	31	1
28	-	1	40	-	1	51	-	1	52	-	1	32	-	1	17	36	1
29	-	1	47	-	1	52	-	1	53	-	1	33	-	1	18	31	1
30	-	1	48	-	1	53	-	1	54	-	1	34	-	1	18	36	1
31	-	1	49	-	1	54	-	1	55	-	1	35	-	1	20	31	1
32	-	1	50	-	1	55	-	1	56	-	1	36	-	1	20	36	1
33	-	1	51	-	1	56	-	1	57	-	1	37	-	1	21	31	1
34	-	1	52	-	1	57	-	1	58	-	1	38	-	1	21	36	1
35	30	1	53	28	1	58	-	1	61	-	1	40	-	1	21	36	1
41	-	1	54	-	1	61	-	1	62	-	1	41	-	1	22	31	1
47	29	1	55	30	1	62	-	1	63	-	1	42	-	1	22	36	1
50	-	1	56	-	1	63	-	1	64	-	1	43	-	1	23	31	1
51	-	1	57	-	1	64	-	1	65	-	1	44	-	1	23	36	1
51	-	1	58	-	1	65	-	1	66	-	1	45	-	1	24	31	1
52	-	1	59	-	1	66	-	1	67	-	1	48	-	1	24	36	1
53	-	1	60	-	1	67	-	1	68	-	1	49	-	1	25	31	1
56	-	1	64	28	1	68	-	1	71	-	1	50	-	1	25	36	1
57	-	1	65	-	1	71	-	1	72	-	1	51	-	1	50	33	1
58	-	1	66	-	1	72	-	1	73	-	1	52	-	1	51	-	1
59	-	1	70	-	1	73	-	1	74	-	1	55	-	1	52	-	1
65	-	1	71	-	1	74	-	1	75	-	1	56	-	1	53	-	1
71	28	1	72	-	1	75	-	1	76	-	1	57	-	1	60	-	1
72	-	1	73	30	1	76	-	1	77	-	1	58	-	1	61	-	1
73	-	1	74	-	1	77	-	1	78	-	1	59	-	1	62	-	1
74	-	1	75	-	1	78	-	1	83	34	1	62	30	1	63	-	1
75	-	1	77	-	1	83	34	1	84	-	1	62	35	1	70	34	1
76	-	1	78	-	1	84	-	1	85	-	1	63	30	1	71	-	1
77	-	1	79	-	1	85	-	1	86	-	1	63	35	1	77	-	1
78	-	1	80	-	1	86	-	1	87	-	1	64	36	1	78	-	1
79	-	1	81	-	1	87	-	1	88	-	1	65	36	1			
80	-	1	82	-	1	88	-	1	93	-	1	66	-	1			
81	-	1	83	-	1	93	-	1	94	-	1	79	35	1	4 226 80	37	1
82	-	1	84	-	1	94	-	1	95	-	1	82	36	1	82	-	1
83	-	1	87	-	1	95	-	1	96	-	1	83	-	1	83	-	1
84	-	1	88	-	1	96	-	1	97	-	1	84	-	1	86	-	1
85	-	1	89	30	1	97	-	1	98	-	1	85	-	1	87	-	1
86	-	1	90	31	1	98	-	1				86	-	1	88	-	1
87	-	1	99	28	1							87	-	1	89	-	1
88	-	1	0 286 00			0 287 00			0 288 00			4 226 00					
89	-	1	0 286 21	32	1	0 287 21	32	1	0 288 00	33	1	0 288 00	33	1	4 226 80	37	1
90	-	1	22	-	1	22	-	1	88	-	1	89	-	1	82	-	1
91	29	1	23	-	1	23	-	1	90	-	1	91	-	1	83	-	1
92	-	1	24	-	1	24	-	1	92	-	1				84	-	1
0 281 00																	
0 281 20	30	1	25	-	1	25	-	1	05	-	1	93	-	1	In accordance with its policy of continuous improvement, the Company reserves the right to change specifications and designs without notice. All illustrations, descriptions, dimensions and weights in this catalogue are for guidance and cannot be held binding on the Company.		
21	-	1	26	-	1	26	-	1	06	-	1	94	-	1			
22	-	1	27	-	1	27	-	1	10	-	1	95					



Head offices

1. 61 & 62, 6th Floor,
Kalpataru Square, Kondivita Road,
Off Andheri-Kurla Road, Andheri (E),
MUMBAI - 400 059.
Tel : (022) 3041 6200
Fax : (022) 3041 6201
Website : www.legrand.co.in

Regional sales offices

2. A-25, Mohan Co-operative
Industrial Estate, Mathura Road,
NEW DELHI - 110 044.
Tel : (011) 3990 2200, 2699 0046,
(011) 2699 0028 / 29 / 30 / 31
Fax : (011) 2699 0047
3. Bhakta Towers, 2nd & 3rd Floor,
Plot No. KB 22, Sector-III, Saltlake,
KOLKATA - 700 098.
Tel : (033) 4021 3535 / 36
Fax : (033) 4021 3537
4. C/203, Corporate Avenue, Atul Projects,
Near Mirador Hotel, Chakala,
Andheri Ghatkopar Link Road,
Andheri - East, **MUMBAI** - 400 099.
Tel : (022) 3385 6200 / 62301000 [IN-001](#)
5. Ferozes Manor,
Situated at 58 Hospital Road,
Shivaji Nagar,
BANGALORE - 560 001.
Tel : (080) 6822 0000 [IN-001](#)
6. 205-208, 2nd Floor, Block - II,
White House, Kundan Bagh,
Begumpet,
HYDERABAD - 500 016.
Tel : (040) 2341 4398 / 67, 4567 1717
Fax : (040) 4567 1730

Branch offices

7. Unit 203, 2nd Floor, Tower- B,
Bestech Business Tower, Sector 66,
Mohali, **CHANDIGARH**-160066.
Telefax : (0141) 2208665, 666 [IN-001](#)
8. 507-510, 5th Floor, Soni Paris Point,
Jai Singh Highway, Banipark,
JAIPUR- 302 016.
Tel / Fax : (0141) 220 8665 / 666
9. 209-A, 2nd Floor, Cyber Heights,
Opp. Indira Gandhi Pratishthan,
Vibhuti Khand, Gomti Nagar
LUCKNOW- 226 010.
Tel : (0522) 431 9316 [IN-001](#)
10. 202 & 203, 2nd Floor, Sunrise,
Forum 100, Burdwan Compound, Lalpur,
RANCHI - 834 001.
Tel : (651) 660 5400
11. A 101-102, Mondeal Heights,
Besides Novotel Hotel, Sarkhej
Gandhinagar Highway (S G Highway),
AHMEDABAD - 380 015.
Tel : (079) 6134 0555 [IN-001](#)
12. 402, Swastik Chambers,
Near Ashwamegh Marriage Hall,
Behind HP Petrol Pump,
Off Karve Road, Erandwane,
PUNE - 411 004.
Tel : (020) 6729 5601 / 602
Fax : (020) 6729 5604
13. Plot No.95, II Floor, Shreyash Heights,
VIP Road, Ramdaspeth,
NAGPUR - 440 010.
Tel : (0712) 662 7857 / 858
Fax : (0712) 662 7859
14. 10 B, (10th Floor), Prestige Center Court
Office Block Vijaya Forum Mall, #183,
N.S.K. Salai, Vadapalani
CHENNAI - 600 026.
Tel : (044) 6612 2800 / 2362 3125 / 35 / 45
Fax : (044) 2362 3165 [IN-001](#)
15. J. B. Manjooran Estate,
Door No 50/1107A9, 3rd Floor,
Bye Pass Junction, Edappally,
COCHIN - 682 024.
Tel : (0484) 280 1921 / 2921, 658 0921
Fax : (0484) 280 1921 / 2921 [IN-001](#)
16. B-5, 1st Floor, Thirumalai Towers,
723, Avanashi Road,
COIMBATORE - 641 018.
Tel : (0422) 222 3634 / 0283
Fax : (0422) 222 3164 [IN-001](#)
17. 204-205, Megapolis Square,
579, M G Road,
INDORE - 452 001.
Tel : (0731) 4999 891 / 892
18. MF-2, Datta's Lords House,
Jammie Chettu Street, Mogalrajapuram,
VIJAYAWADA - 520 010.
Tel : (0866) 248 2393/6393/5393
19. Plot No. 359, Saheed Nagar,
2nd Floor,
BHUBANESWAR - 751 007.
Tel : (0674) 254 0623
20. Unit - 1 & 2, Vijay Park,
Main Chakrata Road,
DEHRADUN- 248 001.
Uttarakhand.
Tel : (0135) 661 6100 [IN-001](#)
21. House No. 97, Ground Floor,
Rajgarh Main Road,
Opp. City Heart Nursing Home,
GUWAHATI - 781 007.
Tel : (0361) 245 8498

Area offices

22. Cabin No. 9, Second Floor,
Madhok Trade Centre,
Madhok Complex, Ferozpur Road,
LUDHIANA - 141 001.
Tel : (0161) 277 0301 / 2 / 3 / 4
23. 94, Udhampur Singh Sarani,
Ground Floor, Ashrampara,
SILIGURI - 734 001.
Tel : (0353) 264 1067
24. A-207, Universal Business
Center, Near Madhuvan circle,
L. P. Savani Road, Adajan,
SURAT - 395 009. [IN-001](#)
25. Aparna Towers, 1st Floor, 2/3,
Bypass Road,
MADURAI - 625 010.
Telefax : (0452) 230 8414
26. 43-9-205,Near srikanya theatre
3rd floor, Plot No 10, Subbalaskhmi
Nagar, Allipuram Ward,
Dondapatty Area,
VISHAKAPATHANAM - 530 016.
Tel : (0891) 663 5652 / 663 9363 [IN-001](#)

CIN-U31909MH2010PTC206487

Technical assistance from Legrand

Telephonic technical assistance for selection of products, technical information, guidance, wiring diagrams and estimation is now made available to you at each Regional Office. Contact the Technical Officer of Legrand at the following telephone numbers

New Delhi : Tel.: (011) 2699 0028, 3990 2200

Kolkata : Tel.: (033) 4021 3535 / 36

Mumbai : Tel.: (022) 3385 6200

Chennai : Tel.: (044) 3024 7200

Hyderabad : Tel.: (040) 2341 4398 / 67, 4567 1717

For other places, contact the nearest
Regional / Branch / Area offices

customer.care@legrand.co.in

legrand®
LIVE THE ADVANTAGE